



27000  
Revised  
2.22.07

2360 Boswell Road  
Chula Vista, CA 91914  
Phone: 619.216.1444  
Fax: 619.216.1474  
E-Mail: tech@explorerprocomp.com

**PRO COMP SUSPENSION**

*Suspension Systems that Work!*

**PARTS LIST:**

ITEM#	DESCRIPTION	QTY.
92-2660	LIGHT BAR	1
90-6542	<b>HARDWARE PACK: Light Bar</b>	1
70-371501806	3/8" X 1 1/2" ALLEN HEAD BOLT	4
73-03700830	3/8" FLAT WASHER	4
72-037100812	3/8" NYLOCK NUT	4

**Part #27000**  
**2005-2006**  
**NISSAN TITAN/ARMADA**  
**4WD & 2WD**  
**Light Bar Kit**

**INSTALLATION  
INSTRUCTIONS**

1. Carefully raise the light bar (92-2660) into position on the center metal section of the front bumper.
2. Center the light bar on the front bumper of the vehicle. Use the upper and lower holes in the light bar as a guide to mark the bumper for drilling.  
*NOTE: Be sure to center the bumper top to bottom and side to side.*
3. Remove the light bar from the vehicle. Center punch and drill an 1/8" pilot hole on the (4) previously made marks on the metal section of the bumper.
4. Drill out the pilot holes using a 13/32" drill bit.
5. Reinstall the light bar to the front bumper using the (4) 3/8" X 1 1/2" Allen head bolt and hardware.
6. Torque all the light bar hardware to 30- 40 ft./lbs. at this time.
7. Install the lights (*Purchased Separately*) to the bar at this time using the instructions and hardware provided with the lights.

**NOTES:**

- ⇒ **After 100 miles recheck for proper torque on all newly installed hardware.**
- ⇒ **Recheck all hardware for tightness after off road use.**